DIRECTIONS FOR APPLICATION



SURFACE PREPARATION

New concrete should be fully cured for seven (7) days and free of all potential contaminants. For best results, air temperature must be above 40° F. If above 95° F or windy during application, keep hydrated with water for one hour. Then allow to dry and proceed with application. Then allow to damp dry and proceed with application. It is recommend that a full mock-up be done to confirm color before applying to entire substrate.

NON-GHP FLOORS or OUTDOOR CONCRETE

1. On any open concrete area simply spray GREEN UMBRELLA[™] COLOR SHIELD with a Green Umbrella[™] recommended sprayer with conical tip. Spray lightly.

Distribute the COLOR SHIELD with an exploded tip bristle broom to ensure uniform coverage.
Allow COLOR SHIELD to penetrate and air dry. Re-apply for 2-3 total coats, depending on color desired.

GHP Floor

1. Profile the surface with diamond impregnated disks as necessary. If glossy finish is desired, do not diamond grind beyond 200 grit resin, to leave the concrete surface open to penetration.

2. On any open concrete area simply spray GREEN UMBRELLA[™] COLOR SHIELD with a Green Umbrella recommended sprayer with conical tip. Spray lightly.

3. Distribute the COLOR SHIELD with an exploded tip bristle broom to ensure uniform coverage.

4. Allow COLOR SHIELD to penetrate and air dry. Fans may be used to increase circulation, but should not blow directly on COLOR SHIELD. You may re-apply for 2-3 total coats, depending on color desired.5. Burnish the surface at 2000 rpm with a Green Umbrella thick black pad.

ROUTINE MAINTENANCE

1. Thoroughly sweep all debris from floor.

2. Mop or Autoscrub with Green Umbrella[™] Cleaner or Green Clean & Degreaser.

