



Application Ratio:
400-600 sq.ft. per gallon
Drying Time:
30-60 min. @75F & 50% RH
Keep dry for 1 hour

**IMPORTANT:**

Read Technical Data Sheet and MSDS prior to application. Follow all directions, including safety information. Installer education, training, and appropriate handling is necessary for product success. Due to the variety of concrete, the applicator must test the product for compatibility prior to full application.



Indoor



Outdoor



Sprayer



Broom



Autoscrub



Burnisher



Grinder

SURFACE PREPARATION

New concrete should be fully cured for seven (7) days and free of all potential contaminants. For best results, air temperature must be above 40° F. If above 95° F or windy during application, keep hydrated with water for one hour. Then allow to dry and proceed with application. Then allow to damp dry and proceed with application.

GHP FLOORS without DYE

1. Hydrate slab for 5 to 10 minutes or until concrete becomes water saturated. Apply Green Umbrella Green Cut™ using a sprayer with a conical tip.
2. Allow the product to sit for 30 minutes. If grinding is to be started immediately do not allow the surface to dry. For more aggressive cutting, let dry overnight and rehydrate with water the next day.
3. Using the desired Green Umbrella Metal™ (GUM) diamond abrasive (50 or 100) begin profile cut. The selection of the abrasive may vary depending on the flatness of the slab. If the first cut is made with a 50 grit GUM it may necessary to cut the floor again with 200 grit GUM. However, if the first GUM used is 100 grit then a second GUM is not necessary.
4. Push slurry into the path of the grinding equipment to allow the cutting agent to aid in the grinding process.
5. Auto-scrub floors, removing all slurry and making certain that floors are free of any Green Cut residue. This will minimize the wear on the Green Umbrella Resin™ (GUR) diamond abrasive and the aggressiveness of the cut on the floor. (Apply Green Umbrella™ Shield & Enhance or Green Umbrella Dry Shield™ to the concrete following product application directions.)
6. Polish floors with GUR 200, 400 or 800 for desired level of gloss. Apply Green Umbrella Microfilm™ to floors to maximize protection from abrasion as well as water, oil and chemical spills.