

CutSpec™ for Concrete Cure:

Product: Solo Cure

For comprehensive manufacturer instructions, visit: <https://greenumbrellasystems.com/solo-cure/>

1) Prior to use, ALWAYS mix using a drill-powered paddle in negative action (top > down). 2) Using a clean, dry, non-metal, low-pressure, high-volume, manual or battery-powered commercial sprayer, spray at 200-600 SF per gallon. Coverage ratio will depend on the finish - broom or hard trowel. 3) Spray evenly without puddling. Allow for 30 minute wet dwell time for full saturation. Do not walk on or allow traffic for 2-3 hours or until dry. 4) Return later with auto scrubber equipped with thick black pads or soft bristle brushes and Green Umbrella DeepClean w/SlipResist to clean and remove the film. 5) For added sheen and gloss, burnish clean surface using a concrete-weighted, ultra-high-speed, propane burnisher equipped with a GreenGloss pad.

[For certified installers, comprehensive manufacturer direction, and support - visit www.GreenUmbrellaSystems.com]

For full CSI specifications: <https://greenumbrellasystems.com/specifications/>

Contact Technical Sales: info@greenumbrellasystems.com